

## FESHM 9180: HAZARD MITIGATION FOR ELECTRICAL WORKERS

### WORK PRACTICES AND SELECTION AND USE OF HAZARD PROTECTIVE CLOTHING AND PERSONAL PROTECTIVE EQUIPMENT

#### Revision History

Author	Description of Change	Revision Date
Michael J. Utes	Section 9 Number 17, clarified that PPE is to be worn until zero voltage verification is assured.	February 2013
John Anderson Jr, and Michael J. Utes	<ul style="list-style-type: none"><li>• Updated NFPA 70E Standard name and year.</li><li>• Updated ASTM standard for flame-retardant clothing.</li><li>• Corrected definition for Limited Approach Boundary</li><li>• Added definition of Arc Rating</li><li>• Updated definition of a Qualified Electrical Worker</li><li>• Updated definition of Working On Energized Live Parts</li><li>• Added Division / Section / Center</li><li>• Defined diagnostic and manipulative energized electrical work activities</li><li>• Added reference to Electrical Safety Subcommittee Guidance Sheets for Fermilab</li><li>• 10. Updated the Special Requirements and Responsibilities section</li></ul>	5 Year Review August 2011

**TABLE OF CONTENTS**

1.0	INTRODUCTION.....	3
2.0	POLICY .....	3
3.0	DEFINITIONS .....	4
4.0	ELECTRICAL WORK ACTIVITIES .....	5
5.0	DISCUSSION OF ELECTRICAL HAZARDS .....	6
6.0	REQUIREMENTS .....	7
7.0	SPECIAL REQUIREMENTS and RESPONSIBILITIES .....	7
8.0	TRAINING.....	8
9.0	ELECTRICAL SAFE WORK PRACTICES .....	8
10.0	USE of the PPE MATRIX .....	10

 <b>Fermilab</b>	ES&H Manual	FESHM 9180 August 2011
---	-------------	---------------------------

## 1.0 INTRODUCTION

Electrical workers are often exposed to specific hazards associated with electricity that pose risk of physical injury. These hazards include shock, electrocution, arc blast, arc flash and electrical burns. These exposures are present for work activities that involve AC Power Distribution System and utilization equipment as well as DC systems.

Electrical safe work practices coupled with the selection and use of protective clothing and personal protective equipment (PPE) are the primary means of mitigating these specific hazards. Special steps of mitigation may also be specified in an individual Hazard Analysis (HA) for non-routine or especially hazardous work activities. The purpose of this Chapter is to outline work practices and provide the requirements and guidance in the selection of PPE so as to reduce overall risk for the electrical worker to an acceptable level. It is imperative that any work within the limited approach boundary of circuits be performed with an acceptable low risk to personnel.

The scope of this Chapter is limited to work activities on AC Power Distribution Systems that operate at 600 VAC and less (NEC “Low Voltage” Class), DC systems 50 volts or higher with a stored capacity exceeding 1kWh, and on utilization equipment that is powered by such distribution systems. Only qualified electricians shall perform installation, maintenance and repair of AC electrical power distribution systems.

These activities typically involve the 277/480 and 120/208 VAC distribution systems commonly found throughout the Laboratory. Work on systems and equipment having operating or supply voltages above 600 VAC is specific to a smaller range of work groups and is performed only by specially trained and qualified electrical workers. The work practices and recommended PPE associated with these higher voltage systems and equipment are to be developed separately by management of these selected work groups, although many of the requirements of this Chapter may be applicable.

The stated requirements, guidelines and recommendations of this Chapter have been developed consistent with the requirements found in Article 130 of NFPA 70E “Standard for Electrical Safety in the Workplace” 2009 Edition.

## 2.0 POLICY

Any work on electrical systems or equipment that has hazardous electrical energy shall preferentially be performed with the equipment de-energized. Exceptions include troubleshooting, inspection, measurements, and testing activities that require the system or equipment under examination to be energized in whole or part. Additional steps and approvals are required for manipulative work on energized systems operating at voltages exceeding 130 VAC terminal-to-ground or 250 VAC terminal-to-terminal. These requirements are found on the backside of the Permit form found in FESHM 9120. Note that signature approvals of the Division/Section/Center Electrical Coordinator, the area Division/Section/Center Head, and approval of the Fermilab Directorate are required. The signature of the FESS Head is also

 <b>Fermilab</b>	ES&H Manual	FESHM 9180 August 2011
---	-------------	---------------------------

required if FESS Operations Department electricians are working within or for another division/section/center. Prior to granting approval, these individuals shall assure themselves that it is necessary to work on the system in an energized condition and not simply a matter of convenience, and that appropriate safety measures have been or will be implemented.

Only qualified workers shall perform work on or near uninsulated or exposed energized live parts.

All qualified workers shall perform work in accord with safe work practices that include the use of personal protective equipment.

All electrical work activities shall be conducted in such a way so as to reduce risk of injury from credible hazards to an acceptably low level.

### 3.0 DEFINITIONS

**Arc Rating** – The value attributed to materials that describe their performance to exposure to an electrical arc discharge. The arc rating is expressed in cal/cm<sup>2</sup> and is derived from the determined value of the arc thermal performance value (ATPV) or energy of breakopen threshold (EBT) (should a material system exhibit a breakopen response below the ATPV value) derived from the determined value of ATPV or EBT.

**Energized Live Parts** - Conductors, buses, terminals, or components that are electrically connected to a source of potential difference that is hazardous. Insulation or barriers normally protect such parts. Work activities frequently involve temporary removal of insulation and/or barriers thereby presenting a hazard to the worker.

**Hazard Analysis (HA)** - The process by which hazards are identified for all anticipated phases of work, all hazards associated with each, and the work processes to be employed to eliminate or reduce those hazards.

**Limited Approach Boundary** – An approach limit at a distance from an exposed live part within which a shock hazard exists. Working inside this boundary is limited to Qualified Persons. Where there is a need for an unqualified person(s) to cross the Limited Approach Boundary, a qualified person shall advise him or her of the possible hazards and continually escort the unqualified person(s) while inside the Limited Approach Boundary. This distance is nominally within three feet six inches (3ft. 6 in.) of uninsulated or exposed non-movable energized live parts less than or equal to 750 volts phase to phase. (NFPA -70E Table 130.2(C))

**Qualified Electrical Person or Worker**, is an individual trained and knowledgeable of the construction and operation of equipment or a specific work method and trained to recognize and avoid the electrical hazards that might be present with respect to that equipment or work

	ES&H Manual	FESHM 9180 August 2011
---	-------------	---------------------------

method. A Qualified Person possesses the skills and techniques necessary to distinguish exposed energized electrical conductors and circuit parts from other parts of the electrical equipment; and the individual is able to determine the nominal voltage of the exposed energized electrical conductors and circuit parts. Additional requirements for the Qualified Person are set forth in NFPA 70E Article 110.6 (D)(1). A person can be considered qualified with respect to certain equipment and methods but still be unqualified for others.

**Working Near Energized Live Parts** – Any activity inside the limited approach boundary.

**Working On Energized Live Parts** – Coming in contact with energized electrical conductors or circuit parts with the hands, feet, or other body parts, with tools, probes, or with test equipment, regardless of the personal protective equipment a person is wearing. There are two categories of “working on”: Diagnostic (testing) is taking readings or measurements of electrical equipment with approved test equipment that does not require making any physical change to the equipment; Manipulative (repair) is any physical alteration of electrical equipment (such as making or tightening connections, removing or replacing components, etc.).

#### 4.0 ELECTRICAL WORK ACTIVITIES

Electrical work activities on either the AC power distribution system or electrical utilization equipment commonly involve both energized and de-energized circuits. While most electrical work activities preferentially involve de-energized circuits, some activities necessarily involve energized circuits. For purposes of this Chapter and in the practical sense, work on energized circuits is classified or described as two distinct types of work.

**Diagnostic Energized Work** is work **ON** exposed energized electrical conductors or circuit parts. LOTO verification, the process where the worker determines by conclusive test that an electrical circuit is either energized or de-energized, is a common diagnostic energized work activity. Examples of other diagnostic energized work activities include troubleshooting, inspection, measurements, and testing of systems or equipment including voltage and current measurements, circuit and signal tracing, and thermal imaging.

**Manipulative Energized Work** generally conveys working **ON** exposed energized electrical conductors or circuit parts where a circuit connection is being closed or opened. Examples of manipulative energized work activities would include replacement of a bolt-on circuit breaker in an energized panel board, tightening connections, replacing a duplex receptacle, switch, or fluorescent light ballast without de-energizing the associated branch circuit. Manipulative energized work activities are allowed only under special circumstances and must be approved by the Fermilab Directorate.

## 5.0 DISCUSSION OF ELECTRICAL HAZARDS

Primary electrical hazards include shock, electrocution, arc flash, arc blast and electrical burns. The actual risk to a worker involved in electrical work activities is highly subjective to the work at hand. Determination of risk cannot be done on the basis of voltage or current alone. Risk involves the combination of both current and voltage or simply stated as the available power. Duration of exposure is also an important contributing factor to risk. The AC Power Distribution System is marked by its capability of being able to provide large amounts of power. However, available power varies by design at different points in the AC power distribution circuit. Equipment design, for either power distribution or utilization equipment, can either increase or lessen exposure to electrical hazards. For example, incoming mains are separately shrouded in panelboards of newer design thereby significantly lowering the risk to the worker for energized work in the panelboard.

Protection against electrical shock, electrocution and electrical burns involves not having any part of the body coming into contact with exposed energized conductors so as to have the body become part of the electrical circuit. The amount of current, path of the current and duration are the critical parameters that determine the extent of personal injury. The human body is sensitive to AC currents as low as one milliamperere. Currents above this level can induce painful shock, muscular contraction and paralysis, asphyxiation, heart fibrillation and paralysis, and tissue burning. Work procedures, insulated tools and insulating PPE are the primary means of avoiding electrical shock, electrocution and electrical burns. Tools and PPE must have insulating voltage ratings in excess of the actual voltages encountered in the work activity. Types of PPE most often used to avoid these hazards include electrically rated gloves and dielectric insulating mats.

Arc flash itself is a much less common occurrence. The most serious arc flash injuries result when untreated clothing is ignited during an arc incident and this can lead to second and third degree burns. Where high arc currents are involved, burns from such arcs can be debilitating and the ignition of clothing can occur even when several feet away. While arc flash can result from electrical equipment malfunction, its occurrence is often the result of inadvertent contact with exposed electrical conductors or misapplication of work practices. The level of hazard presented by arc flash is determined by available fault current, duration of the fault current and physical proximity to the arc flash. Accurate quantification of the arc flash hazard can be accomplished only by a short circuit analysis of the circuit. Performing such an engineering analysis requires detailed knowledge of the circuit, equipment specifications, wire sizes and lengths, conduit sizes, motor loads and fuse characteristics.

Arc flash can be described as either a fault current or short circuit current supported by a conductive plasma of molten metal. Its energy is measured in calories per square centimeter. Protection against arc flash involves shielding the body from the arc flash event. Such shielding involves wearing of protective clothing and/or equipment to protect the hands, face and body from arc flash. Protective clothing is worn to protect the worker from second degree burns and clothing ignition induced by the arc flash. Such clothing may also offer some protection against

 <b>Fermilab</b>	ES&H Manual	FESHM 9180 August 2011
---	-------------	---------------------------

shock. However, due to the explosive effect of some arc events, physical trauma injuries may occur. The PPE requirements do not provide protection against physical trauma.

## 6.0 REQUIREMENTS

1. The conduct of any work on any electrical systems or equipment that has hazardous electrical energy shall be performed in accordance with the policy stated above.
2. Workers who are subject to the risk of exposure to arc flash hazards shall wear untreated natural fiber clothing. Such clothing includes that made of cotton, wool, silk, and/or leather. Incidental meltable fibers, such as elastics found in underwear or socks, are allowed. It is the responsibility of the worker to bear the cost of purchase and maintenance of such clothing.
3. Workers shall inspect PPE for integrity prior to use. PPE exhibiting flaws, excessive soiling, cracks, rips or tears shall not be used. Certain workers may be issued FR clothing in the form of coveralls for arc flash protection. It is the responsibility of the worker to clean and/or launder this flame-resistant clothing in accordance with the manufacturer's requirements.
4. The Hazard Risk Category Classification Matrix, the Protective Clothing and Personal Protective Equipment Matrix, and Electrical Safety Subcommittee guidance sheets included at the end of this Chapter shall be used in determining the PPE for various work activities.
5. Limited approach boundaries shall be maintained, to keep unqualified people from entering, during conduct of electrical work activities so as to protect workers from electrical hazards.

## 7.0 SPECIAL REQUIREMENTS and RESPONSIBILITIES

**Division/Section/Center Heads** shall provide necessary resources to assure implementation of the requirements of this Chapter.

**The ESH&Q Section** shall develop and provide training as necessary in the various elements of this Chapter and in the use and care of PPE.

**The Facility Engineering Service Section** shall stock in the Fermilab stockroom FR coveralls, electrically rated face shields, electrically rated hard hats, and double layer switching hoods.

**Division/Section/Center ESH Departments** shall provide electrically rated gloves to affected trained electrical workers.

## 8.0 TRAINING

Completion of Fermilab course FN000385- Electrical Safety in the Workplace (NFPA 70E) provides training in the elements of this chapter.

## 9.0 ELECTRICAL SAFE WORK PRACTICES

The following points are general safe work practices that apply to electrical work activities. Some are very broad in application while others relate to specific types of work activity.

1. Organize a work plan before starting work. The plan should anticipate and accommodate events that have the possibility of adversely affecting the safe conduct of the work activity.
2. Know that a written Hazard Analysis is required for non-routine work. Read it, understand it, and use it.
3. Ensure related procedures, schematics, drawings, and manuals are available and up-to-date. Consult them if in doubt about any aspect of the work to be performed or the voltages and energies present.
4. If the hazards justify the need, follow the two-person rule with at least one experienced person who has knowledge of the equipment or similar equipment.
5. Communicate with other members of the work group. Establish who is in charge.
6. Take the necessary time to perform the work safely. Don't be rushed or take short cuts.
7. Wear protective clothing and PPE as determined by hazard category to reduce risk of injury from credible hazards. Inspect PPE before using.
8. Do not wear conductive articles of jewelry and clothing, such as watches, bands, bracelets, rings, necklaces, belt buckles or unrestrained metal frame glasses that could reasonably be expected to come in contact with energized conductors, unless such articles are rendered non-conductive by covering with an insulating means.
9. Use the one-hand rule as often as possible.
10. Clear slip and trip hazards and clutter from the work area.
11. Secure the work area as appropriate to ensure the safety of both the workers and passers-by. Observe limited approach boundaries of 3 ft. 6 in. when working with exposed energized components.

12. Assume that all power is on and that stored energy is not relieved.
13. De-energize the equipment whenever possible.
14. When operating a circuit breaker or disconnect switch, turn away and minimize physical exposure to the breaker or switch.
15. Follow LOTO procedures (FESHM 2100) to isolate the hazardous energy source(s).
16. Be mindful of multiple energy sources such as UPS and backfeed of circuits.
17. Remember that verification is the most important step of the LOTO procedure. Proper Personal Protective Equipment shall be worn until zero voltage verification is assured.
18. Labels are not always accurate.
19. Be aware failures of multiphase circuit breakers and disconnects involve failure of one of the poles to operate properly.
20. When verifying absence of voltage from the AC Power Distribution System, measure terminal-to-terminal, terminal to neutral, and terminal-to-ground.
21. Beware of static charge and relaxation charge buildup in capacitors. Beware of charge in coaxial cables.
22. Take necessary steps to isolate remote control of the equipment if appropriate.
23. Energized work and manipulative work can be performed only when absolutely necessary and appropriate authorizations are obtained. If parts of the equipment being worked on can be de-energized, do so.
24. Be sure that personnel performing the work have necessary skills and knowledge to perform the work safely and are acquainted with the particular hazards of the job activity. If the individual performing the work is unfamiliar with the equipment or is being trained, adequate supervision or expertise should be provided.
25. Testing and measuring equipment, when utilized, shall be properly rated for the activity and in good condition. Personnel using such equipment shall be trained in the use of such equipment.
26. If testing equipment is critical to your safety, make sure it is ON and operational.

27. Plan to use test equipment with respect to grounding, to the placement of equipment and probes, to signal levels, and with respect to identifying energized components in the equipment. Pre-connect test probes if possible.
28. Know what is ground.
29. Install and/or maintain low impedance grounding.
30. Understand what is connected to the load.
31. Understand the benefits of current limiting fuses in reducing the affect of arc blast hazards.
32. Observe good housekeeping practices in equipment while performing work.
33. Check the integrity of all high voltage and high current connections.
34. Use a magnet or vacuuming equipment, preferably insulated, to collect metal chips within electrical enclosures.
35. Check integrity of electrical insulation and flash barriers.
36. Use and maintain color-coding, polarity, and phase rotation conventions. (FESHM 9120)
37. Keep 120/208 and 277/480 VAC services physically separated.
38. Understand the difference between resistive and non-resistive ground sticks and when to use each type. Test for continuity before use.
39. After the work is finished, inspect completed work and replace all protective covers before re-energization.
40. Closing in a circuit is generally more dangerous than opening a circuit, especially if new or modified.
41. Older equipment, especially AC power distribution equipment, is generally more dangerous to work on.

## 10.0 USE of the PPE MATRIX

The following matrices adapted from NFPA 70E 2009 shall be used in determining required PPE for various work activities at or below 600 VAC. Table 1 identifies the hazard risk associated with the various task. From there, Table 2 will identify the required clothing and PPE.

 <b>Fermilab</b>	ES&H Manual	FESHM 9180 August 2011
---	-------------	---------------------------

Performing an engineering analysis to determine the risk category is an acceptable alternative to the use of the Hazard Risk Category Classification Matrix. If an engineering analysis is performed to determine incident energy exposure in calories per square centimeter then Table 3 adapted from NFPA 70E 2009 Table 130.7(C)(11) may be used to determine the Hazard/Risk Category. While an engineering analysis of the circuit is not always readily afforded, such analysis can demonstrate reduced risk. Conversely, certain situations can be more dangerous than the norm and additional levels of PPE are appropriate. The Electrical Safety Subcommittee has compiled guidance documents to assist in determining the Hazard/Risk Category for many common tasks at the laboratory for both the AC power distribution and utilization equipment and are available from the following link: <http://esh-docdb.fnal.gov/cgi-bin/ShowDocument?docid=1490>

If an analysis of specific diagnostic and testing work activities indicates that use of certain PPE may actually increase the risk of accident or injury by unduly restricting bodily movements then less restrictive PPE may be acceptable.

Wearing of natural fiber clothing is meant to include long sleeve shirts, long pants and underwear. FR coveralls provided by Fermilab provides an APTV protective rating of 8.2 cal/cm<sup>2</sup>. The addition of natural fiber clothing worn under them will increase the protection because of its protective characteristics and layering.

Leather gloves, while not electrically rated, provide some protection against electrical hazards. Special leather protector gloves are often worn to protect electrically rated gloves. When used, leather gloves should be dry and relatively free of excessive soils, especially oils.

**Table 1 - Adapted from NFPA 70E 2009 - Table 130.7(C)(9) Hazard/Risk Category Classifications**

Tasks Performed on Energized Equipment	Hazard/ Risk Category	Rubber Insulating Gloves	Insulated Hand Tools
<b>Panelboards or Other Equipment Rated 240 V and Below — Note 1</b>			
Perform infrared thermography and other non-contact inspections outside the restricted approach boundary	0	N	N
Circuit breaker (CB) or fused switch operation with covers on	0	N	N
CB or fused switch operation with covers off	0	N	N
Work on energized conductors and circuit parts, including voltage testing (LOTO)	1	Y	Y
Remove/install CBs or fused switches	1	Y	Y
Removal of bolted covers (to expose bare, energized electrical conductors and circuit parts)	1	N	N
Opening hinged covers (to expose bare, energized electrical conductors and circuit parts)	0	N	N
Work on energized electrical conductors and circuit parts of utilization equipment fed directly by a branch circuit of the panelboard	1	Y	Y
<b>Panelboards or Switchboards Rated &gt;240 V and up to 600 V (with molded case or insulated case circuit breakers) — Note 1</b>			
Perform infrared thermography and other non-contact inspections outside the restricted approach boundary	1	N	N
Circuit breaker (CB) or fused switch operation with covers on	0	N	N
CB or fused switch operation with covers off	1	Y	N
Work on energized conductors and circuit parts, including voltage testing (LOTO)	2*	Y	Y
Work on energized electrical conductors and circuit parts of utilization equipment fed directly by a branch circuit of the panelboard	2*	Y	Y
<b>600 V Class Motor Control Centers (MCCs) - Note 2 (except as indicated)</b>			
Perform infrared thermography and other non-contact inspections outside the restricted approach boundary	1	N	N
CB or fused switch or starter operation with enclosure doors closed	0	N	N
Reading a panel meter while operating a meter switch	0	N	N
CB or fused switch or starter operation with enclosure doors open	1	N	N
Work on energized conductors and circuit parts, including voltage testing (LOTO)	2*	Y	Y
Work on control circuits with energized electrical conductors and circuit parts 120 V or below, exposed	0	Y	Y
Work on control circuits with energized electrical conductors and circuit parts >120 V, exposed	2*	Y	Y
Insertion or removal of individual starter “buckets” from MCC - Note 3	4	Y	N
Application of safety grounds, after voltage test	2*	Y	N
Removal of bolted covers (to expose bare, energized electrical conductors and circuit parts) - Note 3	4	N	N
Opening hinged covers (to expose bare, energized electrical conductors and circuit parts) - Note 3	1	N	N
Work on energized electrical conductors and circuit parts of utilization equipment fed directly by a branch circuit of the motor control center	2*	Y	Y

**600 V Class Switchgear (with power circuit breakers or fused switches) Note 4**

Perform infrared thermography and other non-contact inspections outside the restricted approach boundary	2	N	N
CB or fused switch or starter operation with enclosure doors closed	0	N	N
Reading a panel meter while operating a meter switch	0	N	N
CB or fused switch or starter operation with enclosure doors open	1	N	N
Work on energized conductors and circuit parts, including voltage testing (LOTO)	2*	Y	Y
Work on control circuits with energized electrical conductors and circuit parts 120 V or below, exposed	0	Y	Y
Work on control circuits with energized electrical conductors and circuit parts >120 V, exposed	2*	Y	Y
Insertion or removal (racking) of CBs from cubicles, doors open or closed	4	N	N
Application of safety grounds, after voltage test	2*	Y	N
Removal of bolted covers (to expose bare, energized electrical conductors and circuit parts)	4	N	N
Opening hinged covers (to expose bare, energized electrical conductors and circuit parts)	2	N	N

**Other 600 V Class (277 V through 600 V, nominal) Equipment Note 2 (except as indicated)**

Lighting or small power transformers (600 V, maximum)			
Removal of bolted covers (to expose bare, energized electrical conductors and circuit parts)	2*	N	N
Opening hinged covers (to expose bare, energized electrical conductors and circuit parts)	1	N	N
Work on energized conductors and circuit parts, including voltage testing (LOTO)	2*	Y	Y
Application of safety grounds, after voltage test	2*	Y	N
Revenue meters (kW-hour, at primary voltage and current) Insert or removal	2*	Y	N
Cable trough or tray cover removal or installation	1	N	N
Miscellaneous equipment cover removal or installation	1	N	N
Work on energized conductors and circuit parts, including voltage testing (LOTO)	2*	Y	Y
Application of safety grounds, after voltage test	2*	Y	N
Insertion or removal of plug-in devices into or from busways	2*	Y	N

## General Notes (applicable to the entire table):

- (a) Rubber insulating gloves are gloves rated for the maximum line-to-line voltage upon which work will be done.
- (b) Insulated and insulating hand tools are tools rated and tested for the maximum line-to-line voltage upon which work will be done, and are manufactured and tested in accordance with ASM F 1505, Standard Specification for Insulated and Insulating Hand Tools
- (c) Y = yes (required), N = no (not required)
- (d) For systems rated less than 1000 volts, the fault currents and upstream protective device clearing times are based on an 18 in. working distance.
- (e) For systems 1 kV and greater, the Hazard/Risk Categories are based on a 36 in. working distance.
- (f) For equipment protected by upstream current limiting fuses with arcing fault current in their current limiting range (1/2 cycle fault clearing time or less), the hazard /risk category required may be reduced by one number.

## Specific Notes (as referenced in the table):

1. Maximum of 25 kA short circuit current available; maximum of 0.03 sec (2 cycle) fault clearing time.
2. Maximum of 65 kA short circuit current available; maximum of 0.03 sec (2 cycle) fault clearing time.
3. Maximum of 42 kA short circuit current available; maximum of 0.33 sec (20 cycle) fault clearing time.
4. Maximum of 35 kA short circuit current available; maximum of up to 0.5 sec (30 cycle) fault clearing time.

**Table 2 - Adapted from NFPA 70E 2009 - Table 130.7(C)(10)  
 Protective Clothing and Personal Protective Equipment (PPE)**

Hazard/Risk Category Number	Protective Clothing and PPE
<b>Hazard/Risk Category 0</b>	
Protective Clothing, Nonmelting (according to ASTM F 1506-00) or Untreated Natural Fiber	Shirt (long-sleeve) Pants (long)
FR Protective Equipment	Safety glasses or safety goggles (SR) Hearing Protection (ear canal inserts) Leather gloves (AN) (Note 2)
<b>Hazard/Risk Category 1</b>	
FR Clothing, Minimum Arc Rating of 4 (Note 1)	Arc-rated long sleeve shirt (Note 3) Arc-rated pants (Note 3) Arc-rated coverall (Note 4) Arc-rated face shield or arc flash suit hood (Note 7) Arc-rated jacket, parka, or rainwear (AN)
FR Protective Equipment	Hard hat Safety glasses or safety goggles (SR) Hearing Protection (ear canal inserts) Leather gloves (AN) (Note 2) Leather work shoes (AN)
<b>Hazard/Risk Category 2</b>	
FR Clothing, Minimum Arc Rating of 8 (Note 1)	Arc-rated long sleeve shirt (Note 5) Arc-rated pants (Note 5) Arc-rated coverall (Note 6) Arc-rated face shield or arc flash suit hood (Note 7) Arc-rated jacket, parka, or rainwear (AN)
FR Protective Equipment	Hard hat Safety glasses or safety goggles (SR) Hearing Protection (ear canal inserts) Leather gloves (AN) (Note 2) Leather work shoes
<b>Hazard/Risk Category 2*</b>	
FR Clothing, Minimum Arc Rating of 8 (Note 1)	Arc-rated long sleeve shirt (Note 5) Arc-rated pants (Note 5) Arc-rated coverall (Note 6) Arc-rated face shield or arc flash suit hood (Note 10) Arc-rated jacket, parka, or rainwear (AN)
FR Protective Equipment	Hard hat Safety glasses or safety goggles (SR) Hearing Protection (ear canal inserts) Leather gloves (AN) (Note 2) Leather work shoes

---

**Hazard/Risk Category 3**

FR Clothing, Minimum Arc Rating of 25 (Note 1)

Arc-rated long sleeve shirt (AR) (Note 8)  
Arc-rated pants (AR) (Note 8)  
Arc-rated coverall (AR) (Note 8)  
Arc-rated flash suit jacket (AR) (Note 8)  
Arc-rated flash suit pants (AR) (Note 8)  
Arc-rated flash suit hood (Note 8)  
Arc-rated jacket, parka, or rainwear (AN)

FR Protective Equipment

Hard hat  
FR hard hat liner (AR)  
Safety glasses or safety goggles (SR)  
Hearing Protection (ear canal inserts)  
Arc-rated gloves (Note 2)  
Leather work shoes

---

**Hazard/Risk Category 4**

FR Clothing, Minimum Arc Rating of 40 (Note 1)

Arc-rated long sleeve shirt (AR) (Note 9)  
Arc-rated pants (AR) (Note 9)  
Arc-rated coverall (AR) (Note 9)  
Arc-rated flash suit jacket (AR) (Note 9)  
Arc-rated flash suit pants (AR) (Note 9)  
Arc-rated flash suit hood (Note 9)  
Arc-rated jacket, parka, or rainwear (AN)

FR Protective Equipment

Hard hat  
FR hard hat liner (AR)  
Safety glasses or safety goggles (SR)  
Hearing Protection (ear canal inserts)  
Arc-rated gloves (Note 2)  
Leather work shoes

AN = As needed

AR = As required

SR = Selection required

Notes:

1. See Table 130.7(C)(11). Arc rating for a garment is expressed in cal/cm<sup>2</sup>.
2. If rubber insulating gloves with leather protectors are required by Table 130.7(C)(9), additional leather or arc-rated gloves are not required. The combination of rubber insulating gloves with leather protectors satisfies the arc flash protection requirements.
3. The FR shirt and pants used for Hazard/Risk Category 1 shall have a minimum arc rating of 4.
4. Alternate is to use FR coveralls (minimum arc rating of 4) instead of FR shirt and FR pants.
5. FR shirt and FR pants used for Hazard/Risk Category 2 shall have a minimum arc rating of 8.
6. Alternate is to use FR coveralls (minimum arc rating of 8) instead of FR shirt and FR pants.
7. A face shield with a minimum arc rating of 4 for Hazard/Risk Category 1 or a minimum arc-rating of 8 for Hazard/Risk Category 2, with wrap-around guarding to protect not only the face, but also the forehead, ears, and neck (or, alternatively, an arc-rated arc flash suit hood), is required.
8. An alternate is to use a total FR clothing system and hood, which shall have a minimum arc-rating of 25 for Hazard/Risk Category 3.
9. The total clothing system consisting of FR shirt and pants and/or FR coveralls and/or arc flash coat and pants and hood shall have a minimum arc rating of 40 for Hazard/Risk Category 4.
10. Alternate is to use a face shield with a minimum arc rating of 8 and a balaclava (sock hood) with a minimum arc-rating of 8 and which covers the face, head and neck except for the eye and nose areas.

**Table 3 - Adapted from NFPA 70E 2009 - Table 130.7(C)(11) Protective Clothing Characteristics**

<b>Hazard/Risk Category</b>	<b>Clothing Description</b>	<b>Required Minimum Arc Rating of PPE [J/cm<sup>2</sup>(cal/cm<sup>2</sup>)]</b>
0	Nonmelting, flammable materials (i.e. untreated cotton, wool, rayon, or silk, or blends of these materials) with a fabric weight at least 4.5 oz/yd <sup>2</sup>	N/A
1	Arc-rated FR shirt and FR pants or FR coverall	16.74 (4)
2	Arc-rated FR shirt and FR pants or FR coverall	33.47 (8)
3	Arc-rated FR shirt and FR pants or FR coverall, and arc flash suit selected so that the system arc rating meets required minimum	104.6 (25)
4	Arc-rated FR shirt and FR pants or FR coverall, and arc flash suit selected so that the system arc rating meets required minimum	167.36 (40)